



P/N: VOP96L24DC

96W SOLIDRIVE PRO-V

CONSTANT VOLTAGE PHASE-CUT DIMMABLE

CLASS 2 LED DRIVER

iLED SKU#: 8538

The SOLIDRIVE PRO-V Constant Voltage Class 2 LED Drivers from Magnitude Lighting are UL Listed. Drivers with enclosures have a built-in junction box on both the input and output. These drivers are IP 66 rated and suitable for both indoor and outdoor installations. With universal input voltage ranging from 120 to 277VAC, the PRO-V Series of drivers are designed for residential, commercial and industrial applications. Our phase-cut dimming delivers **smooth flicker-free dimming down to 1%** with most LED's and a wide variety of compatible dimmers. As always, a 5-year warranty is a standard on all of Magnitude's products.

Features

- UL Listed Enclosure – built-in junction boxes, (UL 8750 approved)
- Universal input voltage 120 – 277VAC
- Phase-cut dimming flicker free down to 1%
- IP66 – For both Indoor and Outdoor use, Class 2, Class P
- Hiccup Mode protection for short circuits and over-temperature
- Overload Protection – CC Mode

Specifications

Input Voltage	120 – 277VAC ± 10%
Input Current	0.98 A max
Max Output Power	96W
Minimum Load Requirements	8W – 96W
Output Voltage	24V DC
Output Current at Max Load	4100 mA max
Efficiency	>86% at max
Power Factor at Max Load	277VAC >0.90 120VAC >0.95
THD at Max Load	<20%
Env. Protection Rating	IP66
Ambient Operating Temperature	-25°C to +40°C
Expected Lifetime	>50K Hours (at <75°C)
Audible Noise	<24db Class A
Input Wires (white/black)	18 AWG
Output Wires (red/black)	18 AWG
Dimensions (inches)	12.1" x 2.36" x 1.4"
Weight	31 oz.

Wiring Diagram



BEFORE YOU BEGIN

Note: This dimmable transformer requires a **Leading Edge MLV Dimmer or Trailing Edge (ELV) dimmer** for proper dimming operation. See the list of approved dimmers recommended by Magnitude Inc. and Inspired LED for more details. Driver must be installed in a well-ventilated area free from explosive gasses and vapors. Proper operation requires a free flow of air. Driver should be installed by a qualified electrician in accordance with article 450 of the National Electrical Code.

Precautions Before Installing

Check the label to ensure the driver has the proper input voltage and wattage for the job. Check the wire markings to ensure they match the wiring diagram below. If the product has any visible damage, do not install it.

Input Connections/Grounding

Remove wiring compartment cover and desired plastic knockouts to create an input hole. With power turned off, route input wires through the knockout hole, connecting your live wire to **black (L)**, and neutral to **white (N)**. For all wire connections use only UL listed wire nuts and connectors of suitable size and style. **Driver case MUST be grounded in accordance with N.E.C.**

Output Connections

Remove output wiring cover and desired knockouts to create a hole. With power turned off, route the light fixture wires through knockout and connect to driver: positive to the **red (+)** wire and negative to the **black (-)** wire.

Mounting

Select a location capable of supporting the weight of the driver. Use keyholes to mount the driver case using suitable screws.

Output Voltage vs. Load

